



Safety sensors

System components



Actuating magnet EX-BPS 33



Spacer BN 31/BNS 33

Ordering details

Actuating magnet
Spacer

EX-BPS 33
BN 31/BNS 33